### Roadranger

**Eaton®Fuller®Mid-Range Transmissions** 


FS-6105 Series FS-6005 Series





One Great Drivetrain from Two Great Companies

Illustrated Parts List TRIP-0140 May 1990



For the most current information, visit the Roadranger web site at www.roadranger.com

# HOW TO USE THE ILLUSTRATED PARTS LIST

All Lists are arranged the same; available kits, assemblies, drivers' instructions, and technical service literature are listed in the front. Cases, clutch housings, bar housings, mainshafts, countershafts, drive gears and idler follow in order.

# Use of Kits and Assembly Listing (Page 2)

The first column shows on which page kit or assembly is found.

The second column shows Kit References used to identify components of kits on that page.

parts in your stock or find an individual part you may need that allow you to either put kit or assembly together from individual If you do not have kit or assembly in stock, kit references will is in your inventory as part of a kit or assembly.

The third and fourth columns show part number and descrip-

Description	Yoke Assembly 4th-5th
Part#	3316210
Kit Ref.	چ
Page	တ

### **Illustrated Index**

Pages 4 and 5 are an Illustrated Index for this Illustrated Parts List. The isometric drawing is a typical Eaton single countershaft transmission. The proper page on which to find these tems is noted.

### Notes On Illustrations


Illustrations show parts in assembly groups.

Various notes are used where appropriate.

- Current production
- Not used in current production
- Use of lockwire
- Transmission model information

# How to Identify Parts and Obtain Part Numbers.

Example: Yoke 4th-5th



### Determine item number of Yoke Assembly 4th-5th Example: Item Number is 37

TEM	FS	OTY. USED PART NO.	2	KIT REFERENCE
8	4	1JM6028	Lock pin	
88	4	1JM3528	Lock pin	000000000000000000000000000000000000000
5		3316211	Yoke assembly 4th-5th	8
			order assembly 3316210	
ဗ္တ	-	3315763	Yoke bar 4th-5th	
			replaced by 23299	
ō	<u>م</u> 1	23299	Yoke bar 4th-5th	
47	9	227695	Pad	Y1-2-3
ιΩ	ದ	10314	Ball	ഗ്ര

## **Purposes of Kit Reference**

A. To denote the parts included in a kit or an assembly,

### Kit and Assembly Identification for Service Parts B. Used for notes.

A — Denotes Production Assemblies

K — Denotes Service Kit (Unassembled) S — Denotes Service Assembly

### Use of Kit Reference

Assembly 3316210 has reference Y3. This shows that items 37 Items 37 has reference Y3. Item 47 has reference Y1-2-3. and 47 are components of assembly 3316210.

	Œ.	оту.		KI
E	OSED CORRECT	PART NO.	DESCRIPTION	REFERENCE
8	4	1JM6028	Lock pin	
8	4	1JM3528	Lock pin	
8	•	3316211	Yoke assembly 4th-5th	8
			order assembly 3316210	
ဗ္တ	-	3315763	Yoke bar 4th-5th	
			replaced by 23299	
0	ب خ	23299	Yoke bar 4th-5th	
\$	•	227695		3
ည	<del>.</del>	10014		လ
PART NO.	õ		KIT NAME	KIT REFERENCE
331	3316207		Yoke Assembly 2nd-3rd	5
A-5595	395		Yoke Assembly Rev.	- %-
影	3316210		Yoke Assembly 4th-5th	
K-2012	72		Small parts Kit	స
				,

### For parts or service call us Pro Gear & Transmission, Inc.



1 (877) 776-4600 (407) 872-1901

parts@eprogear.com

906 W. Gore St. Orlando, FL 32805



# THIS BOOKLET IS DESIGNED TO IDENTIFY ALL PARTS IN THE FS-6005 AND FS-6105 SERIES TRANSMISSIONS.

# Service Kits and Assemblies available for the FS-6105 Series

Service Kits and Assemblies available for the FS-61	Description	Gasket kit	Shim kit	Small parts kit	Synchronizer kit	Synchronizer kit	Shift bar housing Assembly	Yoke Assembly 2nd-3rd	Yoke Assembly Rev.	Yoke Assembly 4th-5th
nd Assen	Part #	K-2181	K-2183	K-2012	K-2257	K-2017	S1702	3316207	A-5595	3316210
e Kits a	Kit Ref.	J		യ			൜	<u>;</u>	ζ,	\$-
Servic Servic	Page	ı	<del>=</del>	9,11,13	ट	5	=	5	5	13

### **Basic Rebuild**

Description Part#

Kit Ref.

爰 Above kit also include gaskets Basic Rebuild Kit K-2131

Sealants and Lubricants

Description

Part#

Silicone Lubricant 8 oz. size (236.59 cc)-(fleet size) Adhesive Sealant 0.5 cc size (single application size) 71203 71204

Sealant 2 cc size (single application size) 71205

Gasket Sealant 8 milliliter tube (single application size) Silicone Lubricant 4 cc size (single application size) 71206 71231

iquid Thread Adhesive 10 milliliter bottle

(single application size)

## Operating Labels and Instructions

Description Part#

Shift label 21789

## Maintenance and Repair

Description Part#

Series Service Manual - Form Number 196

FS-6105

### Miscellaneous

For Lever / Control information please see Illustrated Parts List form P-599.

For information on the following options please see the Super Parts Book form P-583:

Speedomoter Drives • Yokes & Flanges

Every effort has been make to ensure the accuracy of all information in this brochure. However, Eaton Transmission Division makes no expressed or implied warranty or representation based on the enclosed information. Any errors or omissions may be reported to Training & Publications. Eaton Transmission Division, P.O. Box 4013, Kalamazoo, MI 49003.


## INDEX FOR ILLUSTRATION

Main Case       Page 8         Counterstaft       Page 14         Mainstaft       Page 12         Idler       Page 12         Idler       Page 17         Shift Bar Housing       Page 10         Yokes and Bars       Page 10	DESCRIPTION	PAGE NO.
	Main Case	
	Countershaft Mainshaft	
	Idler Input Shaft Shift Bar Housing	Page 16 Page 17 Page 17 Page 10
	Yokes and Bars	Page 10

## **CLUTCH HOUSING**

Note: Assemblies listed are complete with Bushings and Grease Fittings.

SAE Numbers: denote clutch housing size. See Figure C.



igure D.	
See	
engine.	
n and e	
of transmission and engine. Se	
nt of tra	
d for support	
\$	
nsed	
onuts	
Ž	
æ	
g	
¥	
_	

	Lower Nodal Mount	000
		1.801 3.875
an io modelno		2.211
		Centerline of Housing
	Upper Nodal Mount	60

Size

3.59	.938	0	Angle 30 exaggested for clarification
	1.801	3.875	•
6.850 2.154	_ <del>-</del>	1.750	Centerline of Housing
6.850	2.21	3.465	Centerli

Figure D

7/16 - 14 3/8 - 16

5 5

20 7/8 18 3/8


21 3/4

# INPUT SHAFT AND DRIVE GEAR

Model Series Application: FS-6105

			Dime	Dimensions: Figure A	gure A				Dimension	Dimensions: Figure B
Snan Part No.	Туре	⋖	ω	ပ	٥	.ш	Use Seal #	Use Cover #	L	G
3316168	Pull	1 3/4"	1.18	<b>6</b> 6.	10.44	3.50	3315623	3316171	1.40	I
ъ							3315625	23106	1.25	6.25
21909	Push	1 1/2"	86;	.75	8.61	2.63	235393	3316313	5.08	1.81
21900	Pull	1 3/4"	86;	₩.	10.50	3.75	3315623	3316171	1.40	ı
21899	Push	1 1/2"	86.	₩.	10.50	3.50	21893	3316313	6.73	1.87
21989	Push	1 1/2"	86	.75	10.35	3.50	235393	3316313	6.20	1.94
21990	Push	1 1/2"	<b>86</b>	.75	9.85	2.87	235393	3316313	6.20	1.94
21944	Push	1 3/4"	1.18	75	9.88	3.50	20651	21992	5.83	2.24
									,	

Oil Seal No.# 3315623 is available in K-2131Basic Rebuild Kit





Cut 8392-7/87





Figure F

KIT	טֿ	ס																																			
KITNAME	Chim kit	<b>1 1 1 1 1 1 1 1 1 1</b>																															ויט אוד		7 0404	1612-1	
PART NO.	K-2014																																EASIC BEBIII DIXI		מע		
KIT REFERENCE	Α̈́	No.	70 50	¥ 10	<b>E</b>		nagnetic)	nechanical)	nechanical)	ž									Rear Bearing Cover	or 21979 Rear			Bearing Cover		Bearing Cover	5000 Bill 1900			ical)	/	(lesio	(mail	Ç	Ŷ			
DESCRIPTION	Bearing cuo	Shim 004	Shim 007	Shim 010	Shim 020	020.		Rear bearing cover (mechanical)	Rear bearing cover (mechanical,	Oil seal	Nut	Lockwasher	Nut	Capscrew	Bushing	Lockwasher	Capscrew	Lockwasher	Stud Use with 21901 Rear Bearing Cover	Stud Use with 21947 or 21979 Rear	Bearing Cover	Stud	Use with 21947 Rear Bearing Cover	Spacer	Use with 21947 Bear Bearing Cover	Grease fitting	Lifting eve	Rear bearing cover	12 x 4 brake (mechanical)	Rear Bearing cover	12 x 3 brake (mechanical)	Rear bearing cover	12 x3 brake (magnetic)	Tube	Plug 1/8"	"O" ring	Plug
OTY. ITEM USED PART NO.	31 1 711123	32 3315662	_	or 3315664	or 3315655	,	33   331363/	or 1 33156278	or 2 22020	34 1 241706	36 1 235656	4	4	4	4	46 2 4E04	N	48 4 25E17H	49 4 239432	or 4 239433		or 4 22151		& 4 22152		50 2 11H15	52 1 238370	-		or 1 21947		or 1 21979	•	54 1 21450	-	56 1 14142	58 1 203714
KIT REFERENCE								杀									Æ									S' RK	S¹ RK									6	
DESCRIPTION	For clutch housing	information see page 6	Case	Case	PTO cover	Capecrom	Capscient	Plug	Hand hole cover	replaced by 23380	Hand hole cover	Capscrew	Lockwashers	Gasket	For front bearing cover	information see page 7	For oil seal information	see page 7	Capscrew	Name plate	replaced by 22300	Name plate	replaced by 22300	Name plate	Screw	Shim .004	Shim .007	Shim .010	Shim .020	Capscrew	Plug (magnetic)	Plug	Bearing retainer	Gasket	Rear bearing cover	Speedometer rotor (magnetic)	~
QTY. ITEM USED PART NO.	-		2 1 21766	or 1 21915	4 2 201398	5	<u>.</u>		10 1 206466		or 1 23380	11 4 1C1036	12 4 4E10	15 1 3315659	16 1		17 1		ဖ	19 1 57000		or 1 3312285			20 2 207873	21 3315681	or 3315682	or 3315683	or 3315684	22 2 9G416H	23 1 226858	24 1 239619	-	26 1 3315671	-	30 1 3316160	



Shift bar housing S <sup>5</sup> Gasket S <sup>5</sup>			DESCRIPTION	REFERENCE	PART NO.	N. NAME	REFERENCE
asket		32 1 21804	Yoke bar 2nd-3rd		3316207	Yoke Assembly 2nd-3rd	5-
			replaced by 23298		A-5595	Yoke Assembly Rev.	⊱
Capscrew		or 1 23298	Yoke bar 2nd-3rd		3316210	Yoke Assembly 4th-5th	ይ
Spring RK	_	33 1 3316208	•	5-	K-2012	Small parts kit	స
Ball			order 3316207		S-1702	Shift bar housing Assembly	సి
_		34 4 1JM6028	_				,
Snap ring		35 4 1JM3528					
replaced by 21736		36 1 3315763	-				
Snap Ring							
Plunger		or 1 23299	Yoke bar 4th-5th				
Washer		_	Yoke4th-5th	\$			
Spring -Use with transmission		•	order 3316210	-			
mounted shift lever and remote control	ntrol	38 1 3315755	Retainer front				
Spring - Use with remote control			replaced by 23306				
Spring - Use with transmission		39 1 3315756	Retainer middle				
mounted shift lever and remote control	ntrol	40 1 3315757	_				
Spring - Use with remote control		41 9 233043		iner	BASIC REBUILD KIT	JIFD KIT	
Washer		or 11 233043	Capscrew w/23306 Betainer				
Block reverse		_	Plua	<b>.</b> %	ž	K-2131	
Yoke bar reverse		43 1 229488	Gasket	° €		10121	
replaced by 23296		46 3 238370	Lifting eve	•			
Yoke bar reverse		50 6 227675	Pad	V123			
Yoke reverse Y2				-			
replaced by A-5595					NOTE	KIT S-1702 ALSO INCLLIDES 233113 SHIFT	HET
Yoke reverse						FVFB HOLISING GASKET	
order A-5595 Y <sup>2</sup>							

TE	QTY. ITEM USED PART NO.	DESCRIPTION	KIT REFERENCE	QTY. ITEM USED PART NO.	DESCRIPTION	NIT	PART NO.	KIT NAME	KIT REFERENCE
-	1 710787	Bearing cone	RX	17 2 3315722	Bearing	RK	K-2257	Synchronizer kit	స్త
7	2 228306	Synchronizer cup	స్థ	18 1 3315717	Retainer ring (2.415mm)		K-2017	Synchronizer kit	స
4	1. A-5254	Synchronizer assembly		or 1 3315718	Retainer ring (2.515mm)		K-2012	Small parts kit	හී
		4th-5th	స		Not used in current production	tion		-	
2	1 3315738	Clutch hub		19 1 3315719	Washer	స్ట			
9	1 3316189	Gear mainshaft 4th ("A")		20 1 3316178	Gear mainshaft 1st				
ō	1 3316319	Gear mainshaft 4th ("B")		21 1 A-5246	Synchronizer assembly 1st-reverse	reverse			
7	2 3315737	Bearing	Æ		replaced by A-5542				
ω	1 3315728	Retainer ring (2.415mm)		or 1 A-5542	Synchronizer assembly 1st-reverse	reverse			
ō	1 3315729	Retainer ring (2.515mm)		or 1 23547	Sliding clutch				
		Not used in current production	uo	_	Gear mainshaft reverse				
6	1 3315727	Washer		7	Ball	හ			
유	1 3316187	Gear mainshaft 3rd		29 1 3315704	Washer				
F	2 4124075	Bearing	爱	30 2 21738	Bearing Spacer				
7	1 3315730	Synchronizer cup	సి	4	Bearing	丢			
5	1 3315725	Snap ring	爱	32 1 3313798	Snap ring	爰		1	
<del>1</del>	1 A-5215	Synchronizer assembly		-	Mainshaft				
		2nd-3rd (order A-5541)	సి		replaced by 23320				
ō	or 1 A-5541	Synchronizer assembly		or 1 23320	Mainshaft				
		2nd-3rd	ొ	-	Bearing spacer		BASIC REBUILD KIT	LD KIT	
5	1 3315723	Clutch hub		35 1 21740	Bearing spacer				
91	1 3316182	Gear mainshaft 2nd	హ	-	Bearing spacer		Æ	K-2131	
				37 1 5202047	Bearing cone	RX			


KIT	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \		
KIT NAME	Small parts kit	KIT	K-2131
PART NO.	K-2012	BASIC REBUILD KIT	RK
KIT REFERENCE		ზ <u>ჯ</u>	英
	rshaft 4th ("B" rshaft 3rd rshaft 2nd	Key Countershaft Bearing cone	Bearing cup Spacer
QTY.  TEM USED PART NO. DESCRIPTION	r 1 3316321 1 3316200 1 3316202		14 1 660181 15 1 3316251
KIT REFERENCE	<b>差</b> 差	Æ	
DESCRIPTION	Snap ring Washer Bearing cup	Bearing cone Retainer ring (2.64mm) Retainer ring (2.415mm)	Gear countershaft drive Gear countershaft 4th ("A")
OTY. ITEM USED PART NO. DESCRIPTION	1 1 3315686 2 1 3315687 3 1 1313645		6 1 3316196 7 1 3316198

KIT REFERENCE	妥	英					英			
DESCRIPTION	Bearing cup	Bearing cone	For input shaft and drive gear	information see page 7	Washer	Gear idler	Bearing	Idler shaft	Spacer	Ball
QTY. USED PART NO.	1 675250	1 742259			2 3315673	1 3316163	2 3315674	1 3315672	1 3315676	1 1006
ITEM U	-	2	က		0	F	12	13	14	15

BASIC REBUILD KIT

¥

K-2131



Copyright Eaton and Dana Corporation, 2002. EATON AND DANA CORPORATION hereby grants its customers, vendors, or distributors permission to freely copy, reproduce and/or distribute this document in printed format. THIS INFORMATION IS NOT INTENDED FOR SALE OR RESALE, AND THIS NOTICE MUST REMAIN ON ALL COPIES.



National Institute for AUTOMOTIVE SERVICE EXCELLENCE

### Roadranger MORE TIME ON THE ROAD

The Roadranger® System is an unbeatable combination of the best products from Eaton and Dana – partnering to provide you the most advanced, most trouble-free drivetrain in the industry. And it's backed by the Roadrangers – the most experienced, most expert, most accessible drivetrain consultants in the business.

For spec'ing or service assistance, call 1-800-826-HELP (4357) 24 hours a day, 7 days a week, (Mexico: 001-800-826-HELP (4357)) for more time on the road. Or visit our web site at www.roadranger.com.



FAT•N